

949 RACING

86 Hood Lift Instructions

2012-2021 86

CAUTION: The struts are high pressure nitrogen gas charged. Do not crimp, clamp or drill into body. Take care with strut shaft as any damage will rupture the seal.

1. Install hood bracket as shown onto upper hood hinge bolt. DO NOT loosen lower OEM hood hinge bolt. This bolt maintains hood alignment. Note that brackets are marked left and right. "right" is battery side. Fig 1

Fig 1 - hood bracket



2. Install fender bracket using OEM bolt in fender. Note that brackets are marked left and right. Fig 2

Fig 2 – fender bracket



3. Remove spring locks from struts. Take care not to lose these as they lock the strut onto the ball stud.
4. Use the supplied lube on each socket
5. Install strut onto stud. It may be easier to get the struts onto the studs if you disconnect the OEM hood prop.
6. Reinstall spring locks on all for ball sockets



Contact us if you have any questions or require assistance

949-716-3111 info@949racing.com

Facebook.com/949Racing

Instagram @949racing

<https://www.youtube.com/c/949RacingSuperMiata>